

HANSA
HNS59911404

FRONT



BACK • PUSH BUTTON



5.00" ←

1/2 NPT THREAD
WITH NOTCH



1/4" NOTCH AT 12 O'CLOCK

1/2 NPT THREAD
WITH NOTCH

